Blackhawk TOOLS

THE NEW BRITAIN MACHINE CO.
New Britain, Conn.

U. S. USER NET PRICE SHEET HAND TOOLS

PRICE SHEET TO SUPPLEMENTS OF CATALOG No. W-102

AUTOMATIC TRANSMISSION SERVICE TOOLS

No. **UT-3510-M** EFFECTIVE JANUARY 1, 1959

AUTOMATIC TRANSMISSION SERVICE TOOLS

Part No.	Suggested User Net	Description	Cat. Page
ACT-1B	$12.68	Clutch Tester	AD-387
AD-3B	4.95	Dynaflow Driver Hdl. & Rear Ext. Housing Bushing Driver	B-138
AD-4B	2.63	Adapter: Dynaflow Trans. Case Bushing.	B-138
AD-5B	2.15	Adapter: Dynaflow Front Pump Bushing	B-138
AD-6B	7.73	Adapter: Dynaflow Reaction Flange Bushing	B-138
AD-104B	21.42	Dynaflow Bushing Remover & Installer Set	B-138
ADI-1B	34.46	Dial Indicator Set.	AD-387
ADI-2B	1.43	Dial Indicator Ext. Rod	AD-387
ADI-3B	1.67	Fordomatic Dial Indicator Rod	B-141
ADI-4B	1.05	Dial Indicator Rod	B-142
ADP-10B	8.54	Dynaflow-Powerglide Band Adj. Tool	AD-387
ADP-11B	1.29	Hex. Adpt. for ADP-10B	AD-387
AF-1B	2.15	Adapter: Fordomatic Rear Pump Bushing Driver Hdle. 1951-57	B-141
AF-2B	2.24	Driver Handle: Fordomatic	B-141
AF-3B	1.05	Adapter: Fordomatic Rear Clutch Sun Gear No. A 1951-57	B-141
AF-4B	1.10	Adapter: Fordomatic Rear Clutch Sun Gear No. B 1951	B-141
AF-5B	1.20	Adapter: Fordomatic Rear Clutch Sun Gear No. C 1951-57	B-141
AF-6B	1.05	Adapter: Fordomatic Pin. Carrier 1951-57	B-141
AF-7B	1.38	Adapter: Fordomatic Output Shaft 1951-55	B-141
AF-8B	1.71	Adapter: Fordomatic Front Pump Bushing 1951-57	B-141
AF-9B	1.29	Adapter: Fordomatic Case Bushing 1951-57	B-141
AF-10B	9.48	Fordomatic-Mercomatic Front Band Adj. Tool	B-141
AF-10GB	.68	Gauge Block for AF10B	B-145
AF-11B	20.46	Fordomatic-Mercomatic Rear Band Adj. Tool.	B-141
AF-12B	2.24	Fordomatic Throttle Valve Stop Bending Tool	B-141
AF-13B	$2.15	Fordomatic Manual Shaft Seal Installer	B-141
AF-14B	.38	Fordomatic Throttle Linkage Control Pin.	B-141
AF-15B	2.82	Fordomatic Stator Sprag Inner Race Replacer	B-141
AF-16B	12.36	Fordomatic Throttle Lever Protractor Ga..	B-141
AF-17B	3.11	Fordomatic Rear Pump Discharge Tube Remover	B-141
AF-18B	3.77	Fordomatic Throttle Linkage Gauge (1954)	B-141
AF-19B	2.82	Fordomatic Throttle Linkage Gauge (1951-52-53)	B-141
AF-109B	17.57	Fordomatic Bushing Remover & Installer Set	B-141
*AFB-10B	73.38	Fordomatic Service Kit Board complete with 10 Repair Tools	B-141
*AFB-12B	83.35	Fordomatic Service Kit Board complete with 12 Adjustment Tools.	B-141
*AFBB-10B	5.50	Board Only	B-141
*AFBB-12B	5.50	Board Only	B-141
AFC-1B	18.08	Fordomatic Frt. Clutch Diaphragm Spring Compressor	B-141
AFC-2B	9.48	Fordomatic Rear Clutch Spring Compressor	B-141
AFP-1B	3.11	Front Planet Carrier	AD-387
AFP-2B	3.05	Front Pump Holder	AD-387
AFP-3B	3.35	Fordomatic Planetary Holding Fixture	B-141
AFS-1B	14.27	Fordomatic Output Shaft Sleeve Puller	B-141
AFS-2B	5.21	Fordomatic Output Shaft Sleeve Installer	B-141
AGS-1B	5.21	Governor Sleeve Aligning Tool	AD-387
AH-1B	22.23	Hydramatic Bushing Driver Set	B-132
AH-2B	4.62	Front Pump Bushing Adapter	B-132
AH-3B	4.44	Rear Clutch Drum Adapter	B-132
AH-4B	2.01	Oil Delivery Sleeve Adapter	B-132
AH-5B	1.58	Front Drum Bushing Adapter	B-132
AH-6B	4.16	Reverse Internal Gear Bushing Adapter	B-132
AH-7B	$1.77	Driver for Bushing Adapter	B-132
AH-10B	9.48	Hydra. Front & Rear Band Adj. Tool (Ext.)	AD-387
AH-11B	5.97	Hydra. Front Band Adj. Tool (Int.)	AD-387
AH-12B	.96	Hydra. Rear Band Adj. Gauge (Internal)	AD-387
AJ-1B	5.67	Clutch Unit Holding Fixture	B-142
AJ-2B	3.77	Flywheel Housing Oil Seal Inst.	B-142
AJ-3B	1.67	Flywheel Housing Oil Seal Bush. Prot.	B-142
AJ-4B	.48	Rev. Dr. Flange Retainer	B-142
AJ-5B	30.48	Trans. Hold. Fixture	B-142
AJ-6B	10.44	Fr. Unit Coupling Cover Remover	B-142
AJ-7B	.90	Fr. Unit Coupling Valve Retainer (2)	B-142
AJ-8B	13.59	Speed. Gear Puller	B-142
AJ-9B	8.54	Accum. Cover Remover and Inst.	B-142
AJ-10B	9.50	Fr. Pump Puller	B-142
AJ-11B	7.41	Mainshaft and Play Check Fixture	B-142
AJ-12B	12.36	Rear Clutch Spring Compressor	B-142
AJ-13B	5.67	R. Oil Pump Brg. & Speed. Gear Inst.	B-142
AJ-14B	1.23	Speed. Gear Locating Gauge	B-142
AJ-15B	3.68	R. Un. Clutch Retain.	B-142
AJ-16B	6.92	F. Unit End Play Check Gauge	B-142
AJ-18B	3.44	Throttle Link Gauge.	B-142
*AJB-17B	101.79	Jetaway Service Kit Board with Tools	B-142
*AJBB-17B	5.50	Board only	B-142
AME-1B	5.21	Mainshaft End Play Checking Tool	AD-387
AMS-1B	4.73	Open-Type Snap Ring Remover	AD-387
AOD-1B	5.67	Oil Delivery Sleeve Ring Compressor	AD-387
AOP-1B	13.97	Oil Pressure Gauge	AD-387
AOP-2B	4.23	6' Hose for AOP-1B	B-142
AOP-5B	4.94	Oil Pressure Gauge	B-143
AP-1B	3.59	Powerglide Dr. Hdle.	B-138
AP-2B	2.72	Adapter: Powerglide Transmission Case Rear Bushing Remover	B-138

* Includes Display Material at Cost.

AUTOMATIC TRANSMISSION SERVICE TOOLS (Cont.)

Part No.	Suggested User Net	Description	Cat. Page
AP-3B	$2.34	Adapter: Powerglide Transmission Case Rear Bushing Installer	B-138
AP-4B	1.77	Adapter: Powerglide Clutch Bushing	B-138
AP-5B	2.30	Adapter: Powerglide Front Pump Bushing	B-138
AP-6B	16.65	Powerglide Bushing Remover & Install. Set	B-138
AP-41	6.24	Outer Lever Gauge	Supp.
APF-10B	9.48	Powerflite Reverse Band Adjusting Tool	B-143
APF-11B	16.17	Powerflite Kick-down Band Adjusting Tool	B-143
APF-12B	4.53	Fr. Pump Seal Dr.	B-143
APF-13B	4.92	Manual Shaft Seal Dr.	B-143
APF-14B	8.54	Ex. Housing Rep.	B-143
APF-15B	6.20	Ext. Housing Brg. Remover and Rep.	B-143
APF-16B	17.90	Reaction Shaft Rem. & Rep.	B-143
APF-17B	5.41	Planetary Gr. Trn. Hold. Fixture	B-143
APF-18B	9.50	Clutch Spring Compressor	B-143
APF-19B	7.88	Valve Body Fixture	B-143
APF-20B	17.99	Ext. Housing Fixture	B-143
APF-21B	15.98	Servo Spring Compressor	B-143
*APFB-12B	$132.67	Powerflite Service Kit Board with Tools	B-143
*APFBB-12B	5.50	Board Only	B-143
ARC-1B	.72	Clutch Retainer Bracket	B-143
ARC-2B	11.93	Clutch Spring Com.	AD-387
ARC-3B	.90	Piston Installer	AD-387
ARS-1B	10.26	Rear Servo Spring Com.	AD-387
ARU-1B	3.77	Rr. Unit Hold. Tool	AD-387
AS-1B	.90	Speed. Dr. Gear Spacer	AD-387
ASD-1B	2.15	Dynaflow Front Pump Seal Driver	AD-387
ASD-2B	3.59	Powerglide Front Pump Seal Driver	AD-387
ASD-3B	2.54	Out. Shaft Seal Dr.	AD-387
ASD-4B	2.54	Out. Shaft Seal Dr.	AD-387
ASD-5B	5.97	Fordomatic Fr. Pump Seal Driver	AD-387
ASD-6B	33.06	Com. Set ASD-1B thru ASD-8B	AD-387
ASD-7B	6.54	Hydra. Front Pump Seal Driver	AD-387
ASD-8B	6.63	Adpt. Driver for ASD-1B thru ASD-7B	AD-387
ASP-1B	11.40	Seal Puller (Lg.)	AD-387
ASP-2B	$10.26	Seal Puller (Sm.)	AD-387
*ATB-7B	49.56	Throttle Linkage Bd. with Tools	B-145
*ATB-8B	83.20	Service Kit Board Complete	AD-387
*ATB-9B	85.83	Band Adjusting Board with Tools	B-145
*ATB-16B	132.78	Complete Adj. Board with Tools	B-145
*ATBB-7B	4.00	Throttle Linkage Bd. Only	B-145
*ATBB-8B	5.50	Board Only	AD-387
*ATBB-9B	4.00	Band Adjusting Board Only	B-145
*ATBB-16B	5.40	Complete Adjusting Bd. Only	B-145
ATH-1B	34.70	Transmission Holding Fixture	AD-387
ATL-1B	1.20	Throttle Link. Pins	AD-387
ATL-2B	8.97	Un. Throttle Arm Ga. with Pins	AD-387
ATL-3B	14.27	Un. Throttle Arm Bend	AD-387
*HTB-26B	163.36	Service Kit Board	AD-387
*HTBB-26B	8.75	Board only	AD-387
P-52B	2.72	Tru-Arc Pliers No. 2	AD-387
P-59B	3.95	Snap Ring Pliers	48

* Includes Display Material at Cost.

USE THIS SPACE FOR ADDING NEW ITEMS AS ANNOUNCED.

PRINTED IN U.S.A.